


MaxPac Digital



Thank you for choosing the Chromalox® MaxPac™ - a complete power control solution with industry-best price and performance.

For more than 100 years, customers have relied on Chromalox for the utmost in quality and innovative solutions for industrial heating applications. Chromalox manufactures the world's largest and broadest line of electric heat and control products.

The MaxPac Series SCR Controllers provide the best control for applications where consistent heater/process temperature is critical or where fine resolution of power is required.

Common MaxPac features include:

- Automatic 50/60Hz Line Sensing
- 120 - 575 Vac @ 100 - 1200 Amps
- Isolated Control Circuit
- Flexible I/O Power Wiring
- Easy Customer Interface
- Remote Stop
- Compact Size and Construction
- Touch-Safe Design (option on 100 - 650 Amp models)
- dv/dt Transient Voltage Protection
- MOV Protection
- Built-In Power Distribution
- Soft Start
- 100KA SCCR Rating

Features for the MaxPac I, II, and III include:

- Zero Crossover Firing
- Isolated Control Circuit
 - On/Off Control Inputs:
 - 120 thru 240 Vac
 - 5 - 32 Vdc
 - Dry Contact Closure
 - Proportional (DOT Firing) Inputs:
 - 4 - 20 mA, 0 - 20 mA, 0-5 Vdc, 1 - 5 Vdc, 0 - 10 Vdc
 - Remote Manual Adjust (Optional)
 - Remote Auto/Manual Switch (Optional)
- Electronically Protected with Temperature Warning and Stop System
- Cycle Resolution 3, 5, 7, 11, 13, 17, 19
- Shorted SCR Detection (Optional)
- Soft Start
- Time proportional switching mode
- Staged Heating
- Rotary switch selection of input, leg configuration, modbus

Features for the MaxPac IP include:

- Phase Angle Firing
- Isolated Control Circuit Inputs
 - 0 - 5 mA, 0 - 20 mA
 - 0 - 50 mA, 1 - 5 mA
 - 4 - 20 mA, 10 - 50 mA
 - 0 - 5 Vdc, 0 - 10 Vdc
- Optional Current Limit
- Soft Start
- Line Voltage Compensation
- Zero & Gain Adjustments
- Built-In Manual Adjustment
- Current Limit Adjustment (Optional)

Table of Contents

Section	Topic	Page
1.....	Important Safeguards.....	3
2.....	Description	4
3.....	Before You Install.....	5
4.....	Installation	6
4.1.....	Mounting.....	8
4.2.....	Wiring.....	11
4.2.1	Touch-Safe Design	11
4.2.2	Cover Removal and Installation.....	12
4.2.3	Power/Load Wiring	12
4.2.4	Instrument Power	16
4.2.5	Grounding.....	16
4.2.6	Command Signal Wiring.....	17
4.2.7	Calibration	23
5.....	Specifications	24
6.....	Maintenance	25
7.....	Troubleshooting.....	26
8.....	Parts and Accessories.....	27
9.....	Warranty and Return Information	28
10.....	EC Declaration of Conformity.....	37

1 Important Safeguards

IMPORTANT SAFEGUARDS



The MaxPac User Manual uses this symbol to alert personnel to potential hazards that may damage the equipment.



The MaxPac User Manual uses this symbol to alert personnel to potential hazards that may cause injury or death.

Please read all instructions before installing and operating your MaxPac™.

Before working inside the equipment, confirm that all power has been turned off, locked off, and preferably earthed [grounded] at all points of low and high potential, on both the supply line and load side circuits, as required / permitted by all codes and standards.

Personnel working with or near high voltages should be familiar with modern methods of resuscitation. Contact an area supervisor or safety personnel for more information.

Throughout the MaxPac User Manual, the safety alert and the international electric shock/electrocution symbols will alert you to potential hazards. Safety precautions should always be followed to reduce the risk of personal injury to persons from fire and electrical shock hazards.

Each safety message is preceded by a safety alert symbol and one of three words: DANGER, WARNING, or CAUTION. These mean:



DANGER

You **WILL** be killed or seriously hurt if you do not follow instructions.



WARNING

You **CAN** be killed or seriously hurt if you do not follow instructions.



CAUTION

You **CAN** be hurt if you do not follow instructions.

Damage Prevention Messages:

You will see other **IMPORTANT** messages that are preceded by the word **CAUTION** that are intended to help prevent damage to the MaxPac™ or other equipment. Note that Damage Prevention Messages are **NOT** accompanied by the Safety Alert Symbol.

Key Safety Practices

All personnel working on high voltage electrical equipment must adhere to all national and local regulations, codes, and standards.

Only suitably qualified and experienced persons, who are familiar with this equipment, and the work they are to do, should carry out installation, commissioning, operation, or maintenance of this panel and the associated heater.

Such persons shall adhere to proper high voltage safety procedures, including the use of appropriate personal protective equipment (ppe).

Failure to adhere to any of the above may result in equipment damage, operating losses, injury, or death. Chromalox will not be liable for failure to adhere to all governing regulations, codes, standards, site procedures and information given in this manual.

2 Description

MaxPac I, II, and III

The Chromalox Model MaxPac IP, I, II and III Series are specifically designed for the OEM market. The Chromalox MaxPac I, II and III controllers are highly versatile SCR Power Paks. Firing modes includes On/Off and DOT proportional zero voltage switching. Chromalox's exclusive DOT (Demand Oriented Transfer) firing switches the fewest number of cycles to provide the most precise zero crossover control. At 50% output the units output alternates between one cycle "On" and one cycle "Off". At 51% the output continues with one cycle "On" one cycle "Off" and gradually integrates one extra "On" cycle for the additional one percent. This DOT fired technique also minimizes temperature overshoot, temperature fluctuations and helps extend the loads element life due to reduced thermal shock.

The power SCR assemblies consist of one, two or three SCR's connected back to back with a semiconductor fuse, RC Snubber and MOV protection. The firing circuit is based on common integrated circuit. Diagnostic indicators are included as well as plug-in terminal blocks for easy customer interface.

MaxPac IP

The Chromalox MaxPac IP utilizes Single Phase, Phase Angle firing to modulate power to an inductive or resistive load. Phase Angle control has the advantage of proportioning every cycle thereby providing very fine resolution of power. Fast responding loads in which the resistance changes as a function of temperature require Phase Angle control. The MaxPac IP offers a Soft Start feature that assures that the load power is gradually increased from zero to the value set by the command signal in the event of a power interruption. In addition, optional Current Limit is used to protect the load, SCR controller and the total system from large surge currents that could occur at start-up.

† This can be set to three cycles 'On' / three cycles 'Off' (see section on installation options).

3

Before You Install



Immediately after receiving your MaxPac I, II, III or IP Series Controller, visually inspect the shipment packaging and record any damage on the shipping documents. Unpack the controller and carefully inspect for obvious damage due to shipment. If any damage has occurred, YOU must file a claim with the carrier company, since the carrier company will not accept a claim from the shipper (Chromalox).

Be sure to check the model number and verify that you have received the correct Model of controller.

If the controller is not installed and placed into operation immediately, it should be stored in a cool, dry environment. Temperature extremes and excessive moisture can damage the controller.

Before choosing a location in which to mount your MaxPac, please consider the following:

Temperature

When mounting the SCR unit in a control panel, attention should be paid to the enclosure temperature. The SCR is rated to perform at its nameplate current rating in temperatures up to 50°C (122°F). Ensure that adequate ventilation is provided or some other method of maintaining the correct cabinet temperature is used.

Cleanliness

Careful attention must be paid in areas subjected to airborne particles. The efficiency of the heat sinks relies on their conducting surfaces being maintained in a clean manner. (See the Maintenance Section.)

Dampness

High humidity or hosing down a unit should be avoided.

Clearance

Choose a location that will provide adequate spacing around the unit when mounted. This will ensure proper air flow necessary to cool the device.



Installation


The forced air design of the MaxPac series allows mounting in any direction. It is essential that air flow through the enclosure be planned to insure proper cooling.

The 100 amp through 300 amp open design Max-Pac allow the input line power to connect from either of two directions.


The output power can only be connected from one direction. The three mounting configurations are shown below (MaxPac II Three-Phase Two-Leg Shown).

Open designs above 300 amps and all closed designs allow incoming and outgoing wiring in either direction.


Configuration One



Configuration Two




Configuration Three




Examples of Proper Air Flow

Since hot air rises naturally, it is not recommended that cooling air enter from the top and exhaust at the bottom of the enclosure.



**Forced Air In
(Recommended)**



**Forced Air Out
(Not Recommended)**

4 Installation



**READ AND UNDERSTAND BEFORE
CARRYING OUT THE WORK DETAILED BELOW**

Please read all information in this section before beginning the installation of your MaxPac.

Installation of the MaxPac requires three steps:

1. Mounting
2. Power wiring
3. 120 **or** 230 VAC 50/60hz for instrument power. See 4.2.4, pg. 16.

4.1 - Step 1: Mounting

Before mounting your MaxPac, please read the section titled “Before You Install’ on page 5 for a description of an ideal environment for the unit’s operation.

The space required for mounting the MaxPac Power Pak depends upon the model. The table below refers to the figures on the following pages. These figures illustrate the dimensions and mounting holes for the various MaxPac Power Pak models. Please refer to these figures before mounting your unit.

Figure	Model
1.....	100A, 150A, & 200A 2-Leg Open Type
1.....	100A, 150A, 200A, & 300A 1-Leg Open Type
2.....	100A, 150A, & 200A 3-Leg Open Type
3.....	300A 2-Leg Open Type
4.....	100A, 150A, 200A, 300A & 400A 1-Leg Touch-Safe
4.....	400A 1-Leg Open Type
5.....	100A, 150A, 200A, 300A & 400A 2-Leg Touch-Safe
5.....	400A 2-Leg Open Type
6.....	100A, 150A, 200A, 300A & 400A 3-Leg Touch-Safe
6.....	300A & 400A 3-Leg Open Type
7.....	550A & 650A 1-Leg Touch-Safe
7.....	550A & 650A 1-Leg Open Type
8.....	550A & 650A 2-Leg Touch-Safe
8.....	550A & 650A 2-Leg Open Type
9.....	550A & 650A 3-Leg Touch-Safe
9.....	550A & 650A 3-Leg Open Type
	800-1200 Amp units, consult factory

IMPORTANT: Please note that the figures on the following pages are **not drawn to the same scale.**




Figure 1




Figure 2




Figure 3




Figure 4




Figure 5




Figure 6




Figure 7




Figure 8




Figure 9

4.2 - Step 2: Wiring

Careful attention must be paid when attaching the wiring to the MaxPac to ensure proper and safe operation. This section contains detailed information on how to connect the power, resistive load, ground, and command signal wiring.


	 WARNING
	Hazardous Voltage: Only qualified personnel should perform electrical wiring for the MaxPac Power Paks. LETHALLY HIGH VOLTAGES are associated with this equipment and are dangerous if improperly installed.

IMPORTANT: Select installation wiring that is in accordance with the National Electrical Code and any local standards that may be applicable.

4.2.1 - Touch-Safe Design

If the MaxPac model you purchased is of a Touch-Safe design, follow the steps on the following page to install the electrical wiring. This will ensure the wiring is done properly while maintaining the Touch-Safe feature. If your MaxPac is of an Open design below 400 Amps, disregard this subsection.

The following is a detailed drawing of a Touch-Safe unit:



4.2.2 - Steps for Touch-Safe Design Cover Removal and Installation

Remove Cover:

1. Loosen the thumb screws on both ends of the cover.
2. Lift the cover from the base.

Install Wiring:



3. Attach the wires to the bus bars in accordance with the instructions in the next section.
4. Choose the entrance and exit directions for the wiring as desired.
5. After the wiring is complete, remove the tape from the inside of the wire gaskets of the windows that the power wiring will enter or exit.

	 WARNING
	<i>Hazardous Voltage: DO NOT remove the tape from the back of the windows that are not used, as this maintains the Touch-Safe feature.</i>

Replace Cover:

6. Angle the end of the cover without screws towards the “fan-end” of the unit.
7. Slip that end into place first while allowing the wiring to pass through the desired windows.
8. Slip the opposite end of the cover into place.
9. Tighten all thumb screws.

4.2.3 - Line/Load Power Wiring

	 WARNING
	<i>The following wiring instructions are for the Digital Maxpac only. If using Analog Maxpac, contact factory for appropriate wiring schematics. Analog Maxpacs are designated as MXPCI,II, or III followed by the number 1, 2, 3, or 4 under the firing mode.</i>


The following illustrations depict how to connect the MaxPac to a resistive load. Make sure you refer to the correct illustration for the MaxPac series you have purchased. The MMAX and MXPC Series Controllers can operate on both 50 and 60Hz lines and feature automatic line sensing capabilities.

For the power/load drawings:


On open design units up to 300 Amps, X1, X2, X3, L1, L2, and L3 refer to copper lugs.

On open design units 400 Amps and greater and all Touch-Safe designs, X1, and X2, and X3, L1, L2, and L3 refer to bus bar connections.


MaxPac I



MaxPac II




MaxPac III




CAUTION

IMPORTANT: The I²t fuses installed on the SCR are designed to protect the SCR from faults on the load connection side. They are **NOT** intended to provide wire protection.

MaxPac III



MaxPac IP



CAUTION

IMPORTANT: The I²t fuses installed on the SCR are designed to protect the SCR from faults on the load connection side. They are **NOT** intended to provide wire protection.

The bus bars are designed to accept NEMA standard two-hole crimp lugs in accordance with the charts below.

The following drawings show proper installation of the crimp lugs on the bus bars:




Illustration 1: View From Rear Ventilated Panel

All bolts must mount with excess bolt lengths toward the fuse to maintain required electrical clearances.




Illustration 2: View From Top

Smaller wire, #1 through #8, often used for power distribution, can be connected to both sides of the load bus. Wiring must be bent slightly to align with the windows in the top of the touch safe units.

Touch-Safe Units
100 - 400 Amps

Input Bus	Output Bus
Up to (3) 1/0 - 300 mcm (70 mm ² — 150 mm ²)	Up to (10) #8 - #1 (10 mm ² — 50 mm ²)
Up to (2) 350 - 500 mcm (185 mm ² — 240 mm ²)	Up to (3) #1/0 - 300 mcm (70 mm ² — 150 mm ²)
	Up to (2) 350 - 500 mcm (185 mm ² — 240 mm ²)

550 - 650 Amps

Input Bus	Output Bus
Up to (4) 1/0 - 300 mcm (70 mm ² — 150 mm ²)	Up to (12) #8 - #1 (10 mm ² — 50 mm ²)
Up to (3) 350 - 500 mcm (185 mm ² — 240 mm ²)	Up to (4) #1/0 - 300 mcm (70 mm ² — 150 mm ²)
	Up to (3) 350 - 500 mcm (185 mm ² — 240 mm ²)

800 - 1200 Amps Open Design

Input and output bus drilled to accommodate qty (4) 1/0 - 500 mcm NEMA standard two-hole crimp lugs per phase.

The power wires must always mount on the fuse side of the bus bar. This is essential for maintaining the required spacing between phases and the sides and to align with the openings in the top. The only exception to this is when using power distribution using connectors of size #8 to #1. There is adequate spacing for these connectors to mount on both sides of the bus bar if necessary. The bolt head should always be on the outside of the bus (side away from the fuse) with the bolt extending toward the fuse. Flat washers should be used on both the bolt head and the nut and a lockwasher should be under the nut. The Touch Safe MaxPac is designed to allow both input and output wiring to enter/exit in either direction. On the 550 amp and 650 amp models it is necessary to mount the wire in the holes that maximize the distance for the wire to exit the enclosure. This maximizes the distance from the cover to the un-insulated connector. When using the power distribution feature and mounting terminals on both sides of the bus bar, the wires mounted on the outside of the bus bar must be bent inward slightly to align with the opening in the top. All wiring, especially the larger wires should be bent prior to mounting to the bus bars. Do not use the bus bars as an anchor to bend the power cables.

4.2.4 - Instrument Power



MaxPac requires 120 or 230 VAC 50/60Hz for instrument power. This voltage supplies power for the control circuits, fans, high temperature warning indicator, and shorted SCR Indicators (see Fig. 1 on page 21).

This supply is fused on the main circuit board.



4.2.5 - Grounding

The MaxPac uses electrically isolated SCR's. The enclosure will therefore be at the potential of the panel to which it is mounted. Holes are provided on the back of both sides of the MaxPac for NEMA standard two hole crimp lugs (the same as used on the bus bars) for additional grounding as may be required.


IMPORTANT	
Chassis is provided with hole pattern for standard NEMA two-hole crimp lugs.	

	 WARNING
	<p><i>Hazardous Voltage: This Electrical Equipment must be installed by a qualified person and effectively grounded in accordance to the National Electric Code and local codes.</i></p>

4.2.6 - Command Signal Wiring

	 WARNING
<p>The following wiring instructions are for the Digital MaxPac only. If using Analog MaxPac, contact factory for appropriate wiring schematics. Analog MaxPacs are designated as MXPCI,II, or III followed by the number 1, 2, 3, or 4 under the firing mode.</p>	

Please refer to the following figure for illustrations of the 6-, 8-, and 10-pin input terminals.



*Only one customer input is allowed, eg. J3 pins 1 & 2 contact control may not be used at the same time as J2 pins 6 & 7 (4-20 mA)

**Instrument power 4 VA maximum

MaxPac I, II, and III

On/Off Control Signals

AC Input – The 120 – 230 VAC signal lines are connected to terminal J1-7 & 8. An input voltage of 120 to 230 VAC turns the power On. The turn OFF voltage for the power control is 0 VAC.

DC Input – The 5 – 32 VDC signal lines are connected to terminal J3-1&4. An input voltage of 5 to 32 VDC turns the power On. The turn OFF voltage for the power control is 0 VDC.

NOTE: For AC or DC input to be used for ON/OFF control, SW1 rotary switch must be set to position 0 and unit must be jumpered for AUTO

Contact Closure Input – The dry contact signal lines are connected to terminal J3-1&2. A closed contact turns the power On. The turn OFF is an open contact.

Process Analog Control Signals


The MaxPac II accepts 0 – 5/1 – 5/0 – 10 VDC and 4 – 20 mA input signals, they are factory calibrated. The following signals are connected to:

- 0 - 5 VDC: Terminal J2 - 9(+) & 7(-)
- 1 - 5 VDC, 11 - 5 VDC: Terminal J2 - 5(+) & 7(-)
- 0 - 10 VDC: Terminal J2 - 10(+) & 7(-)
- 4 - 20 mA, 10 - 20 mA: Terminal J2 - 6(+) & 7(-)

Auto/Manual Input

The MaxPac I, II and II can be wired to make it possible to select an input from either a temperature/process controller or a manual input potentiometer. A switch is used to select between the input from a 1K potentiometer or a linear control input (see input connections).

The unit is shipped with a jumper from terminals 4 and 5 of terminal block J2. This jumper must be removed when connecting the auto/manual switch and potentiometer.



Demand Indicator

The LED demand indicator is located on the main PC board and is viewable through the cover. With the On/Off control option, the indicator will display steady “on” and steady “off”. With the DOT Firing or Time-Proportional options, the indicator will display the firing sequence.

SCR Control Board

The control board provides the following functions:

The low voltage dc to operate the circuitry:

A switching regulator circuit converts the instrument power to +8 VDC.

The power distribution for the cooling fans:

The incoming instrument power is routed to the fan power terminals.

Add fusing as required for fan power requirement.

The signal condition for the on/off input and analog inputs:

The 120 to 240 on/off input is isolated by an opto-coupler. The DC and contact closure inputs are buffered by the circuitry.

The drive signal to the SCR trigger boards:

The temperature alarm:


The heat sink temperature is derived from a resistive temperature detection (RTD) sensor mounted on the heat sink. This is then compared to two set points.

The first alarm is a warning and activates the externally connected device.

This allows time to correct the problem before the second alarm inhibits the firing circuit.

The Shorted SCR Alarm:

When a short is detected the externally connected device output is activated.



The method of setting the MaxPac for desired mode of operation is as follows:

Input Command Selection

The unit can be set to drive its output in response to the following command inputs:

- Analog potentiometer
- Analog inputs: 4-20mA (or 0-20mA), 0-5Vdc (or 1-5Vdc), 0-10V
- Digital ON/OFF inputs: AC ON/OFF, DC ON/OFF

To select between any of these inputs, set the MaxPac as indicated in the table below:

Input Command Select	Method of Selection
Potentiometer	Select MANUAL mode by leaving no connection between J2.4 & J2.5. The rotary switch selection at SW1 is ignored when in MANUAL mode OR Select AUTO mode by jumpering J2.4 & J2.5, and then set rotary switch at SW1 to position 1
ON / OFF (will turn output in if either AC or DC ON/OFF inputs are energized)	Select AUTO mode by jumpering J2.4 & J2.5, and then set rotary switch at SW1 to position 0
0-10Vdc	Select AUTO mode by jumpering J2.4 & J2.5, and then set rotary switch at SW1 to position 2
0-5Vdc	Select AUTO mode by jumpering J2.4 & J2.5, and then set rotary switch at SW1 to position 3
1-5Vdc	Select AUTO mode by jumpering J2.4 & J2.5, and then set rotary switch at SW1 to position 4
0-20mA	Select AUTO mode by jumpering J2.4 & J2.5, and then set rotary switch at SW1 to position 5
4-20mA	Select AUTO mode by jumpering J2.4 & J2.5, and then set rotary switch at SW1 to position 6
Note: SW1 position 7 is reserved for factory use, and should not be used	

Phase Selection and Firing Mode

SW3 selects the phase selection and firing method of the MaxPac.



Normally, this switch should be left in its factory-installed position. If it should become necessary to change it, set only accordance to the table below. Choosing a setting that does not match your unit's number of phases and legs will result in the unit entering alarm mode and turning the output off after an initial attempt to turn outputs on.

SW3 Position	Selection	Note
0	Reserved for factory use	Do Not Use this Selection
1	DOT for MXPCI	Caution: Do not choose this setting if your unit is a MXPCII or MXPCIII type
2	DOT for MXPCII	Caution: Do not choose this setting if your unit is a MXPCI or MXPCIII type
3	DOT for MXPCIII	Caution: Do not choose this setting if your unit is a MXPCI or MXPCII type
4	Time Proportional for MXPCI	Caution: Do not choose this setting if your unit is a MXPCII or MXPCIII type
5	Time Proportional for MXPCII	Caution: Do not choose this setting if your unit is a MXPCI or MXPCIII type
6	Time Proportional for MXPCIII	Caution: Do not choose this setting if your unit is a MXPCI or MXPCII type
7	Reserved for factory use	Do Not Use this Selection

LED Indicators

LEDs and their function are as follows:

Designator	Name	Description
LD2	Output Demand Indication	This LED blinks on according to the switching of output
LD3	Switch SCR1	OFF in normal operation. Turns ON if shorted SCR is detected in one direction. Blinks rapidly if phase voltage is not present or if SCR is shorted in both directions.
LD4	Switch SCR2	OFF in normal operation. Turns ON if shorted SCR is detected in one direction. Blinks rapidly if phase voltage is not present or if SCR is shorted in both directions.
LD5	Switch SCR3	OFF in normal operation. Turns ON if shorted SCR is detected in one direction. Blinks rapidly if phase voltage is not present or if SCR is shorted in both directions.

Alarm Output

The form C contact at J14 will be in the alarmed state in any of the following conditions:

- If any shorted SCR is detected. One or more of the shorted SCR LEDs LD3-LD5 will be lit in this case
- If missing Zero Cross transitions are detected at the SCRs. Typically, this is caused by missing power on one or more phases, or from incorrect detection of phase sequence. One or more of the shorted SCR LEDs LD3-LD5 will be blinking in this case
- If sensed temperature of the heat sink at an SCR junction exceeds 200 degrees Fahrenheit or 93 degrees Celsius. The Overtemp output will also be engaged in this case.
- If sensed phase sequence does not match the setting of selector SW3. (Normally, SW3 should be left in its factory-set state. See caution in section titled, "Phase Selection and Firing Mode").

Remote Stop

When it is necessary to disable or enable the output, connect a dry contact between J3 – 3 & 4. When it is closed, the power control will disable the output.


CAUTION

IMPORTANT: This stop overrides the control input only. It will NOT protect against faulted or damaged SCRs.

Shorted SCR Detection (optional)

This feature provides a means of alerting an operator to a problem with the system. An external indicated lamp or relay can be connected to J1 – 5 & 6 (See Fig. 2). This indicator must be rated for the instrument power applied to J1 -1 & 2. Three diagnostic LEDs show which SCR pair is faulted. These lights are synchronized with the demand indicator and can only indicate while the demand is active.

The MaxPac includes built in filtering to avoid false shorted SCR alarms, with parameters adjustable through ModBus communications.




Heat Sink Over-Temperature

An external lamp or relay may be connected to J1 – 3 & 4 (see Figure 2) (this must be rated for the instrument power applied to J1 – 1 & 2). This will provide an indication to the operator that the heat sink has approached an unsafe temperature level of 200°F (93°C). The unit will enter a stop mode if the temperature rises to 212°F (100°C).


Input Terminals (MaxPac I, II, and III):

FIG 1




**120-230 INSTRUMENT POWER
REQUIRED ON ALL CONFIGURATIONS**

FIG 2




**SHORTED SCR AND
HI TEMP INDICATORS.**

FIG 3




MANUAL CONTROL INPUT SIG

FIG 4




0-5 / 1-5 VDC PROPORTIONAL INPUT SIG

FIG 5




4-20mA PROPORTIONAL INPUT SIG

FIG 6




0 +10 VDC PROPORTIONAL INPUT SIG

FIG 7




120-240 ON/OFF CONTROL

FIG 8




EXTERNAL +5-32 VDC ON/OFF

FIG 9



DRY CONTACT ON/OFF

FIG 10



REMOTE SHUTDOWN

MaxPac IP


The Chromalox MaxPac IP is a solid-state proportional power controller that utilizes a Phase Angle firing technique to modulate power to an inductive or resistive load. Separate adjustable Zero, Gain, Manual Bias, and Current Limit potentiometers are provided along with screw type plug-in connectors for input signals, Emergency Stop, and optional Remote Manual Bias with 0 - 100% dial. All units have thermostat protection with N.C. contacts.

Start-up

The MaxPac IP has been factory calibrated for 4 - 20mA input. Be sure the operating voltage and signal input are correctly applied. Also, make sure the Emergency Stop, if used, has N.O. contacts and jumper pins 4 & 5 on the 10-pin connector if remote manual bias are not used. Please read the information on calibration at the end of this section for current limit settings for loads with extreme hot to cold ratios or those that are overrated. Other ranges may be field calibrated by use of zero and gain potentiometers.



IMPORTANT: With the Current Limit option, the current transformer must be terminated properly to prevent it from being damaged.



Customer Connection

4.2.6 - Calibration (MaxPac IP):

Many high-temperature heating elements exhibit extreme hot to cold resistance ratios. Heating elements composed of Platinum, Molybdenum, Tungsten, and Tantalum, to name a few, draw excessive current on start-up. Depending on the mass of the elements, these "high starting currents" may exist for extended periods of time. Generally, once the elements have achieved their normal operating temperatures, the current drawn through the MaxPac Power Pak will fall within the rating of the unit. For these types of loads, we recommend adjusting the I LIM (Current Limit) to 50% or less. This will decrease voltage as well as current.

1. Set Current Limit (I LIM) pot to 0% for full current output (CCW).
Current Limit is for limiting current for loads that have extreme hot to cold resistance ratios or are overrated. We recommend for these types of loads to adjust I LIM (Current Limit) to 50% or less. This will also decrease voltage as well as current. 0% Current Limit gives 100% current output (CCW). 100% Current Limit gives 10% current output (CW).
2. Set Manual (MAN) pot to zero so unit will not be biased above input (CCW).
Manual control adjustment provides a means of setting the output level of the MaxPac Power Pak in the absence of controlling instrumentation. The manual control signal value "adds" to the controlling instrument to set minimum output. The desired output power level may be set by adjusting the manual control. This value of output will then be present even in the absence of a control signal.
3. Set Remote Manual pot to zero output so unit will not be biased above input (CCW). (Jumper pins 4 & 5 if not used.)
Remote Manual control adjustment provides a means of setting the output level of the MaxPac Power Pak in the absence of controlling instrumentation. The Remote Manual control is also effective when a control signal is connected. The Remote Manual control signal value "adds" to the controlling instrument to set minimum output. The desired output power level may be set by adjusting the Remote Manual control. This value of output will then be present even in the absence of a control signal. Connect Remote Manual pot wire to Pin 4 (CCW), Pin 5 (W), and Pin 6 (CW) of plug-in connector.
4. Check for open contact for Emergency Stop.
Emergency Stop inhibits all SCR trigger pulses regardless of the level of the input signal or manual potentiometer. For Emergency Stop, close contact Pin 7 to Pin 8 of plug-in connector. Leave contacts open for operation.
5. Check for polarity of input signal.
6. Adjust input signal to low end of scale.
Zero Adjust control sets the power output starting point or reference. Thus, it effectively cancels positive inputs to the MaxPac Power Pak.
EXAMPLE: 0 - 5 mA input → set to 0 mA input
4 - 20 mA input → set to 4 mA input
7. With power off, connect line voltage and load as shown.
8. Connect meter to input and output.
WARNING: Set meter to correct scale to read proper input or output.
9. Apply power to unit.
10. Adjust input signal to low end of scale.
11. Using the Zero pot, adjust the output voltage just to zero volts.
12. Adjust input signal to top end of scale.
Gain Adjust Control sets the maximum power output for maximum input signal.
EXAMPLE: 0 - 5 mA input: set to 5 mA input
4 - 20 mA input: set to 20 mA input
13. Using the Gain pot, adjust output voltage just to maximum volts.
14. Repeat steps 11, 12, 13, and 14 until no adjustment is necessary of Zero and Gain pots for proper output voltage indication. Voltage output should increase proportionally to the signal input applied.
15. Adjust input signal to low end of scale (zero voltage output).
16. With Manual pot at zero for zero voltage output, adjust (CW) to 100% for full voltage output. Voltage output should increase proportionally. Return to CCW position and output will decrease to zero output.
17. With Remote Manual at zero for zero voltage output, adjust (CW) to 100% for full voltage output. Voltage output should increase proportionally. Return to CCW position and output will decrease to zero output.
18. With Manual pot (CW) at 100% and I LIM (Current Limit) at 0%, adjust I LIM towards 100% noting that voltage output decreases with the adjustment of the Current Limit pot. Adjust Current Limit pot for your application, if needed.
19. Turn POWER OFF and remove meters. TEST COMPLETE.

5 **Controller Configuration**

6 Specifications

MaxPac I, II, and III

Control Inputs

Accepts all of the following as standards:

On/Off Control

Signal Input
120 thru 230 VAC \pm 10% (4 VA Maximum)
5-32 VDC
Contact Closures

Proportional Control

Signal Input Input Impedance
4 - 20 mA..... 50 Ohms
1 - 5 VDC..... 10k Ohms or greater
0 - 5 VDC..... 9k Ohms or greater
Remote Manual Adjust
Auto/Manual Switch

Instrument Power 120 or 230 VAC
50/60 Hz

Output Voltage 0 - 99% RMS line voltage
($E_o = V_{supply} - 1.5V$ SCR forward drop)

Resolution (proportional) Better than 0.1%

Line Voltage120 - 575 VAC, 50/60 Hz
CE 400 VAC 50 Hz

Load Current Rating100, 150, 200, 300, 400,
550, 650, 800, 1000, 1200A

Ambient Temperature0 - 50°C (32 - 122°F)

SCR Capability

DielectricWithstand capability
Surge Rating 1500V RMS min.
Typically fifteen (15) times nominal RMS rating for 8.3 milliseconds
IsolationSCRs isolation 2500V
Input-output isolation 1500V

Heat SinkGround potential up to 650 Amps

High TemperatureAC Voltage Output
Indicator Output 100 mA @ Instrument Power

Shorted SCRAC Voltage Output
Indicator Output 100 mA @ Instrument Power

MaxPac IP

Control Inputs

Accepts all of the following as standards:

Phase Angle Control

Signal Input Input Impedance
1 - 5, 0 - 5mA 1K Ohms
4 - 20, 0 - 20mA 250 Ohms
10 - 50, 0 - 50mA 100 Ohms
Optional Remote Manual Adjust

Fan Power 120 or 230 VAC
50/60 Hz

Output Voltage 0 - 99% RMS line voltage
($E_o = V_{supply} - 1.5V$ SCR forward drop)

Resolution (proportional) Better than 0.1%

Line Voltage 120, 208, 240, 277, 380,
480 and 575 VAC
 \pm 10% 50/60 Hz

Load Current Rating .. 100, 150, 200, 300, 400,
550, 650, 800, 1000, 1200A

Ambient Temperature0 - 50°C (32 - 122°F)

SCR CapabilityWithstand capability
1500V RMS min.
Typically fifteen (15) times nominal RMS rating for 8.3 milliseconds

Surge RatingTypically fifteen (15) times nominal RMS rating for 8.3 milliseconds

IsolationSCRs isolation 2500V
Input-output isolation 1500V


Heat SinkGround potential up to 650 Amps

Thermostat4 Amps @ 120V resistive
2 Amps @ 240V resistive
N.C. Contact Standard

Current Limit10 - 100% of rated output current

Soft Start25% demand per second
typical reset speed
8.3 milliseconds

7 Maintenance



Environmental Issues:

Temperature:

When mounting the SCR unit in a control panel attention should be paid to the enclosure temperature. The SCR is rated to perform at its nameplate current rating in temperatures up to 50°C (122°F). Ensure that adequate ventilation is provided or some other method of maintaining the correct cabinet temperature is used.

Cleanliness:

Careful attention must be paid in areas subjected to airborne particles. The efficiency of the heatsinks rely on their conducting surfaces being maintained in a clean manner. (See Maintenance Section)

Dampness:

High humidity or hosing down should be avoided.

Connections:

Ensure that all electrical connections are secure and tight. (See Maintenance Section)

Fusing:

The I²t fuses installed on the SCR are designed to protect the SCR's from faults on the load connection side. They are NOT intended to provide wire protection.

Maintenance


Connections:

Loose connections in the power wiring will generate hot spots, which will cause degradation of electronic equipment. Periodic inspections should be made to ensure that connections are secure and that there are no signs of excessive heating such as discoloration etc.

Filters:

Many high power control enclosures rely on blowers or fans to maintain a safe operating temperature. The filters used with these devices should be changed on a periodic basis to insure adequate enclosure cooling is maintained.

8 Troubleshooting



The following guidelines cover most of the common problems that could occur with the MaxPac. They are not intended to be, nor can they be, absolutes to cover every possible failure.

Problem

Note: Heater load must be connected to Test.

No Power or unbalanced power to the load.

If Demand Light is “Off”

1. Check incoming line power. Verify that fans are running
2. Check the instrument power.
3. Check the fuse on the main board.
4. Verify the input signal.
5. Check that remote stop J3 - 3 to 4 is open.
6. Check that the J2 - 4 to 5 is Jumpered.
7. Verify that heat sink is not in over temperature mode.

If Demand Light is “On”

1. Check the connections to SCR trigger board.
2. Check the power fuses (I²t).
3. Look for damage on the trigger board.

Observation	Possible Root Cause
LD3 – SCR1 light is ON and Alarm relay engaged	Shorted SCR1
LD4 – SCR2 light is ON and Alarm relay engaged	Shorted SCR2
LD5 – SCR3 light is ON and Alarm relay engaged	Shorted SCR3
LD3 – SCR1 light is blinking and Alarm relay engaged	Missing phase or phase error, SCR1
LD4 – SCR2 light is blinking and Alarm relay engaged	Missing phase or phase error, SCR2
LD5 – SCR3 light is blinking and Alarm relay engaged	Missing phase or phase error, SCR3
Over temp output conducts, Alarm relay engaged, and heater output still functions	Heat Sink Temperature greater than 200°F (93°C) detected but all outputs less than 212°F (100°C)
Over temp output conducts, Excessive temperature of heat sink and Alarm relay engaged, heater output still functions	Heat Sink Temperature greater than 200 °F (93°C) detected but all outputs less than 212°F (100°C)

Diagnostics with Safety Cover Removed

Observation	Possible Root Cause
Heartbeat LED not blinking	Loss of electronics AC power. Check fuse.



Parts and Accessories

	WARNING
	<i>The following parts list is for the Digital MaxPac version only. If using Analog MaxPac, contact factory for appropriate parts lists. Analog MaxPacs are designated as MXPCI, II, or III followed by the number 1, 2, 3, or 4 under the firing mode.</i>

Instrument Power Fuse

<u>Chromalox Part Number</u>	<u>Description</u>
0024-01312	Fuse, 0.125A, 2 AG

500 VAC I²T Fuse

0024-07634	200 Amp I ² t Fuse
0024-07630	250 Amp I ² t Fuse
0024-07632	400 Amp I ² t Fuse
0024-03116	500 Amp I ² t Fuse
0024-07633	700 Amp I ² t Fuse
0024-03118	800 Amp I ² t Fuse
0024-03200	1000 Amp I ² t Fuse

600 VAC I²T Fuse

0024-07644	125 Amp I ² t Fuse
0024-07645	175 Amp I ² t Fuse
0024-07636	250 Amp I ² t Fuse
0024-07637	400 Amp I ² t Fuse
0024-07638	500 Amp I ² t Fuse
0024-07639	700 Amp I ² t Fuse
0024-07640	800 Amp I ² t Fuse
0024-07646	1000 Amp I ² t Fuse
0024-01191	1200 Amp I ² t Fuse

Fans

<u>Chromalox Part Number</u>	<u>Description</u>
0045-00231	120 VAC rated Fan
0045-00235	230 VAC rated Fan

Crimp Lug Chart

For Open Design 400 - 1200 Amp and all Touch-Safe Models:

<u>Conductor Size</u>	<u>Chromalox Part #</u>	<u>Panduit Part #</u>
#8 AWG (10mm ²)	0135 - 10002	LCD8 - 14A - L
#6 AWG or #6 Weld (16mm ²)	0135 - 10003	LCD6 - 14A - L
#4 AWG or #4 Weld (25mm ²)	0135 - 10004	LCD4 - 14A - L
#2 AWG (35mm ²)	0135 - 10005	LCD2 - 56B - Q
#1 AWG or #2 Weld (50mm ²)	0135 - 10006	LCD1 - 56C - E
#1/0 AWG or #1 Weld (70mm ²)	0135 - 10007	LCD1/0 - 12 - X
#2/0 AWG or #1/0 Weld (70mm ²)	0135 - 10008	LCD2/0 - 12 - X
#3/0 AWG or #2/0 Weld (95mm ²)	0135 - 10009	LCD3/0 - 12 - X
#4/0 AWG or #3/0 Weld (120mm ²)	0135 - 10010	LCD4/0 - 12 - X
250 MCM or #4/0 Weld (150mm ²)	0135 - 10011	LCD250 - 12 - X
300 MCM (150mm ²)	0135 - 10012	LCD300 - 12 - X
350 MCM (185mm ²)	0135 - 10013	LCD350 - 12 - 6
400 MCM (240mm ²)	0135 - 10014	LCD400 - 12 - 6
500 MCM (240mm ²)	0135 - 10015	LCD500 - 12 - 6

SCR Replacement

Be sure to replace thermstrate interface material and torque as follows:

<u>MFG Part #</u>	<u>SCR Part #</u>	<u>Thermstrate Part #</u>	<u>Torque inch/lb to Heat Sink to Terminals</u>	<u>Torque inch/lb</u>
SKKT92	0002 - 47560	0029 - 00700	44 inch/lb (5 Nm)	26 inch/lb (3Nm)
SKKT162	0002 - 47559	0029 - 00822	44 inch/lb (5 Nm)	44 inch/lb (5 Nm)
SKKT250	0002 - 47537	0029 - 00719	44 inch/lb (5 Nm)	80 inch/lb (9 Nm)
SKKT500	0002 - 47557	0029 - 00814	44 inch/lb (5 Nm)	106 inch/lb (12 Nm)

MaxPac I, II, and III

Accessories:

<u>Part Number</u>	<u>Description</u>
G0135-28193	SCR Trigger Board
G0135-28194	On/Off Main Firing Board
0135 - 20117	Potentiometer & Remote/Manual Switch

MaxPac IP

Accessories:

<u>Part Number</u>	<u>Description</u>
0135 - 28002	Firing Circuit 120, 240 VAC
0135 - 28006	Firing Circuit 208, 277, 480 VAC
0135 - 28037	Firing Circuit 380 VAC

10 **Warranty and Return Information**

Warranty Notice

The Warranty below complies with the federal law applicable to products manufactured after December 31, 1976. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

Chromalox Warranty

Chromalox instruments and controls are warranted against defects in workmanship and materials. No other express warranty, written or oral, applies with the exception of a written statement from an officer of Chromalox®, Inc.

Warranty Period

This warranty extends for one year from date of shipment from the factory or authorized distributor.

Limitations

Products must be installed and maintained in accordance with Chromalox instructions. Users are responsible for the suitability of the products to their application. There is no warranty against damage resulting from corrosion, misapplication, improper specification or other operating conditions beyond our control. Claims against the carrier company for damage in transit must be filed by the buyer.

Returns

Items returned to Chromalox must be accompanied by a Return Authorization Number. This number may be obtained from Chromalox' Customer Service Department at the phone number listed below.

The Return Authorization Number must appear on the exterior of the shipping carton and on the shipping documents.

Defective items will be repaired or replaced at our option and at no charge.

Return the defective part or product, freight prepaid, to the following address:

Chromalox, Inc.
1347 Heil Quaker Blvd.
LaVergne, TN 37086-3536

Phone: (615) 793-3900

Fax: (615) 793-3563

Ordering Information for MaxPac I

Model SCR Power Pack

MXPC I Single Phase SCR Power Pack

Code Control Configuration

5 Proportional Control, DOT Zero-Crossover Firing, Command Input Signals: 4-20mA, 0-5 VDC, 1-5 VDC (via Modbus RTU/485 only), 0-10 VDC, Remote 0-1000 OHM Potentiometer w/Manual Override, Modbus RTU/RS485 Communications. RTD Heat Sink Temperature Sensor with Two Set-Points, Automatic Line Sensing 50/60HZ, Remote Permissive Stop Input, Form "C" Dry Contact Alarm Output, Staged Heating w/Digital Calibration Zero / Span Adjustments(4-8 mA, 8-12 mA,12-16 mA,16-20 mA (via Modbus RTU/RS485 only), LED Diagnostics: Command Input, Main/Trigger Boards Running, SCR Status per Phase, Diagnostic Kit via Modbus RTU/RS485: Highest Heat Sink Temperature, Last Heat Sink Temperature, Highest and Lowest Ambient Temperature, Line Frequency Monitoring, Third Party Certifications: UL, cUL, CE, DEMKO (650 A and below).

Code Current at 50°C (122°F)

01	100 Amp	Open Design
02	100 Amp	Touch Safe Design
03	150 Amp	Open Design
04	150 Amp	Touch Safe Design
05	200 Amp	Open Design
06	200 Amp	Touch Safe Design
07	300 Amp	Open Design
08	300 Amp	Touch Safe Design
09	400 Amp	Open Design
10	400 Amp	Touch Safe Design
11	550 Amp	Open Design
12	550 Amp	Touch Safe Design
13	650 Amp	Open Design
14	650 Amp	Touch Safe Design
15	800 Amp	Open Design
16	1000 Amp	Open Design
17	1200 Amp	Open Design

Code Line Voltage

1	120 VAC - 480 VAC
2	575/600 VAC

Code Instrument Power

1	120 VAC 50/60 Hz
2	230 VAC 50/60 Hz

Code Compression Lug Kits (Open Design up to 300 Amps) For Other Ranges See Crimp Lug Chart

L0	None
L1	100 - 150 Amp PAK 1(#2 - 4/0)/connection
L2	200 - 300 Amp PAK 1(1/0 - 500mcm)/connection

MXPC I - 5 03 1 1 L1 (Continued on next page)

Ordering Information for MaxPac I (continued)

Code	Fusing Option (1)
	For < 500VAC Applications, Select One
F00	None
F01	100 -150 Amp PAK (200 Amp Fuse)
F02	200 Amp PAK (250 Amp Fuse)
F03	300 Amp PAK (400 Amp Fuse)
F04	400 Amp PAK (500 Amp Fuse)
F05	550 Amp PAK (700 Amp Fuse)
F06	650 Amp PAK (800 Amp Fuse)
F07	800 Amp PAK (1000 Amp Fuse)
F08	1000 Amp PAK (1200 Amp Fuses)
F09	1200 Amp PAK (Two 1000 Amp Fuses)
	700 V Fuses for 575/600 V Applications, Select One
F10	100 Amp PAK (125 Amp Fuse)
F11	150 Amp PAK (175 Amp Fuse)
F12	200 Amp PAK (250 Amp Fuse)
F13	300 Amp PAK (400 Amp Fuse)
F14	400 Amp PAK (500 Amp Fuse)
F15	550 Amp PAK (700 Amp Fuse) Ω
F16	650 Amp PAK (800 Amp Fuse)
F17	800 Amp PAK (1000 Amp Fuse)
F18	1000 Amp PAK (1200 Amp Fuse)
F19	1200 Amp PAK (Two 1000 Amp Fuses)
Code	Remote Man. Adjust/Auto Man. Switch
0	None
1	Pot with 0 - 100% dial and Local/Remote Single Turn 1K Potentiometer (Proportional Control Only) (Supplied loose for customer mounting)

MXPC I - 5 03 1 1 L1 F01 1 Typical Model Number

- 1) SCR Fusing is for semiconductor protection only, not wire protection.
- 2) Supplied Loose for Customer Mounting.

Note:

Storage Temperature 14°F to 158°F (-10°C to 70°C).
CE application requires filters.

Crimp Lug Chart				
Chromalox #	Panduit #	Conductor Size	Torque	
			In-Lb.	Nm
0135-10002	LCD8-14A-L	#8 AWG	180	20
0135-10003	LCD6-14A-L	#6 AWG or #6 Weld	180	20
0135-10004	LCD4-14A-L	#4 AWG or #4 Weld	180	20
0135-10005	LCD2-56B-Q	#2 AWG	180	20
0135-10006	LCD1-56C-E	#1 AWG or #2 Weld	180	20
0135-10007	LCD1/0-12-X	#1/0 AWG or #1 Weld	480	54
0135-10008	LCD2/0-12-X	#2/0 AWG or #1/0 Weld	480	54
0135-10009	LCD3/0-12-X	#3/0 AWG or #2/0 Weld	480	54
0135-10010	LCD4/0-12-X	#4/0 AWG or #3/0 Weld	480	54
0135-10011	LCD250-12-X	250 MCM or #4/0 Weld	480	54
0135-10012	LCD300-12-X	300 MCM	480	54
0135-10013	LCD350-12-6	350 MCM	480	54
0135-10014	LCD400-12-6	400 MCM	480	54
0135-10015	LCD500-12-6	500 MCM	480	54

Note: NEMA standard two hole copper crimp lugs only.

Ordering Information for MaxPac IP

Model SCR Power Pack

MXPC IP Single Phase SCR Power Pack

Code Control Configuration

- 1 Phase Angle Control (Accepts: 0-5 mA, 0-20 mA, 0-50 mA, 1-5mA, 4-20 mA, 10-50 mA, 0-5Vdc, 0-10 VDC)
- 2 Phase Angle Control with Current Limit

Code Current at 50°C (122°F)

Code	Current	Design
01	100	Amp Open Design
02	100	Amp Touch Safe Design
03	150	Amp Open Design
04	150	Amp Touch Safe Design
05	200	Amp Open Design
06	200	Amp Touch Safe Design
07	300	Amp Open Design
08	300	Amp Touch Safe Design
09	400	Amp Open Design
10	400	Amp Touch Safe Design
11	550	Amp Open Design
12	550	Amp Touch Safe Design
13	650	Amp Open Design
14	650	Amp Touch Safe Design
15	800	Amp Open Design
16	1000	Amp Open Design
17	1200	Amp Open Design

Code Voltage

1	120 VAC
2	208 VAC
3	240 VAC
4	277 VAC
5	480 VAC
6	575 VAC

Code Fan Power

1	120 VAC 50/60 Hz
2	230 VAC 50/60 Hz

Code Compression Lug Kits (Open Design up to 300 Amps)

For Other Ranges See Crimp Lug Chart

L0	None (Select for all Touch Safe Designs and for over 30 Amp Open Design)
L1	100 - 150 Amp PAK 1(#2 - 4/0)/connection
L2	200 - 300 Amp PAK 1(1/0 - 500mcm)/connection

MXPC IP - 2 03 1 1 L1 (Continued on next page)

Ordering Information for MaxPac IP (continued)

Code	Fusing Option (1)
	For < 500VAC Applications, Select One
F00	None
F01	100 -150 Amp PAK (200 Amp Fuse)
F02	200 Amp PAK (250 Amp Fuse)
F03	300 Amp PAK (400 Amp Fuse)
F04	400 Amp PAK (500 Amp Fuse)
F05	550 Amp PAK (700 Amp Fuse)
F06	650 Amp PAK (800 Amp Fuse)
F07	800 Amp PAK (1000 Amp Fuse)
F08	1000 Amp PAK (1200 Amp Fuses)
F09	1200 Amp PAK (Two 1000 Amp Fuses)
	700 V Fuses for 575 V Applications, Select One
F10	100 Amp PAK (125 Amp Fuse)
F11	150 Amp PAK (175 Amp Fuse)
F12	200 Amp PAK (250 Amp Fuse)
F13	300 Amp PAK (400 Amp Fuse)
F14	400 Amp PAK (500 Amp Fuse)
F15	550 Amp PAK (700 Amp Fuse)
F16	650 Amp PAK (800 Amp Fuse)
F17	800 Amp PAK (1000 Amp Fuse)
F18	1000 Amp PAK (1200 Amp Fuse)
F19	1200 Amp PAK (Two 1000 Amp Fuses)
Code	Remote Man. Adjust/Auto Man. Switch
0	None
1	Pot with 0 - 100% dial and Local/Remote Switch(2) Single Turn 1K Ω Potentiometer

MXPC IP -2	03	1	1	L1	F01	1	Typical Model Number
-------------------	-----------	----------	----------	-----------	------------	----------	-----------------------------

- 1) SCR Fusing is for semiconductor protection only, not wire protection.
- 2) Supplied Loose for Customer Mounting.

Note:

Storage Temperature 14°F to 158°F
(-10°C to 70°C).
CE application requires filters.

Crimp Lug Chart				
Chromalox #	Panduit #	Conductor Size	Torque	
			In-Lb.	Nm
0135-10002	LCD8-14A-L	#8 AWG	180	20
0135-10003	LCD6-14A-L	#6 AWG or #6 Weld	180	20
0135-10004	LCD4-14A-L	#4 AWG or #4 Weld	180	20
0135-10005	LCD2-56B-Q	#2 AWG	180	20
0135-10006	LCD1-56C-E	#1 AWG or #2 Weld	180	20
0135-10007	LCD1/0-12-X	#1/0 AWG or #1 Weld	480	54
0135-10008	LCD2/0-12-X	#2/0 AWG or #1/0 Weld	480	54
0135-10009	LCD3/0-12-X	#3/0 AWG or #2/0 Weld	480	54
0135-10010	LCD4/0-12-X	#4/0 AWG or #3/0 Weld	480	54
0135-10011	LCD250-12-X	250 MCM or #4/0 Weld	480	54
0135-10012	LCD300-12-X	300 MCM	480	54
0135-10013	LCD350-12-6	350 MCM	480	54
0135-10014	LCD400-12-6	400 MCM	480	54
0135-10015	LCD500-12-6	500 MCM	480	54

Note: NEMA standard two hole copper crimp lugs only.

Ordering Information for MaxPac II

Model SCR Power Pack

MXPC II Three Phase SCR Power Pack

Code Control Configuration

5 Proportional Control, DOT Zero-Crossover Firing, Command Input Signals: 4-20 mA, 0-5 VDC, 1-5 VDC (via Modbus RTU/485 only), 0-10 VDC, Remote 0-1000 OHM Potentiometer w/Manual Override, Modbus RTU/RS485 Communications. RTD Heat Sink Temperature Sensor with Two Set-Points, Automatic Line Sensing 50/60HZ, Remote Permissive Stop Input, Form "C" Dry Contact Alarm Output, Staged Heating w/Digital Calibration Zero / Span Adjustments(4-8 mA, 8-12 mA, 12-16 mA, 16-20 mA(via Modbus RTU/RS485 only), LED Diagnostics: Command Input, Main/Trigger Boards Running, SCR Status per Phase, Diagnostic Kit via Modbus RTU/RS485: Highest Heat Sink Temperature, Last Heat Sink Temperature, Highest and Lowest Ambient Temperature, Line Frequency Monitoring, Third Party Certifications: UL, cUL, CE, DEMKO (650A and below).

Code Current at 50°C (122°F)

01	100 Amp	Open Design
02	100 Amp	Touch Safe Design
03	150 Amp	Open Design
04	150 Amp	Touch Safe Design
05	200 Amp	Open Design
06	200 Amp	Touch Safe Design
07	300 Amp	Open Design
08	300 Amp	Touch Safe Design
09	400 Amp	Open Design
10	400 Amp	Touch Safe Design
11	550 Amp	Open Design
12	550 Amp	Touch Safe Design
13	650 Amp	Open Design
14	650 Amp	Touch Safe Design
15	800 Amp	Open Design
16	1000 Amp	Open Design
17	1200 Amp	Open Design

Code Line Voltage

1	120 VAC - 480VAC
2	575/600 VAC

Code Instrument Power

1	120 VAC 50/60 Hz
2	230 VAC 50/60 Hz

Code Compression Lug Kits (Open Design up to 300 Amps) For Other Ranges See Crimp Lug Chart

L0	None
L1	100 - 150 Amp PAK 1(#2 - 4/0)/connection
L2	200 - 300 Amp PAK 1(1/0 - 500mcm)/connection

MXPC II - 5 03 1 1 L1 (Continued on next page)

Ordering Information for MaxPac II (continued)

Code	Fusing Option (1)
	For < 500VAC Applications, Select One
F00	None
F01	100 -150 Amp PAK (200 Amp Fuse)
F02	200 Amp PAK (250 Amp Fuse)
F03	300 Amp PAK (400 Amp Fuse)
F04	400 Amp PAK (500 Amp Fuse)
F05	550 Amp PAK (700 Amp Fuse)
F06	650 Amp PAK (800 Amp Fuse)
F07	800 Amp PAK (1000 Amp Fuse)
F08	1000 Amp PAK (1200 Amp Fuses)
F09	1200 Amp PAK (Two 1000 Amp Fuses)
	700 V Fuses for 575 V Applications, Select One
F10	100 Amp PAK (125 Amp Fuse)
F11	150 Amp PAK (175 Amp Fuse)
F12	200 Amp PAK (250 Amp Fuse)
F13	300 Amp PAK (400 Amp Fuse)
F14	400 Amp PAK (500 Amp Fuse)
F15	550 Amp PAK (700 Amp Fuse)
F16	650 Amp PAK (800 Amp Fuse)
F17	800 Amp PAK (1000 Amp Fuse)
F18	1000 Amp PAK (1200 Amp Fuse)
F19	1200 Amp PAK (Two 1000 Amp Fuses)
Code	Remote Man. Adjust/Auto Man. Switch
0	None
1	Pot with 0 - 100% dial and Local/Remote Single Turn 1KΩ Potentiometer (Proportional Control Only) (Supplied loose for customer mounting)

MXPC II - 5	03	1	1	L1	F01	1	Typical Model Number
--------------------	-----------	----------	----------	-----------	------------	----------	-----------------------------

- 1) SCR Fusing is for semiconductor protection only, not wire protection.
- 2) Supplied Loose for Customer Mounting.

Note:
Storage Temperature 14°F to 158°F
(-10°C to 70°C).

Crimp Lug Chart				
Chromalox #	Panduit #	Conductor Size	Torque	
			In-Lb.	Nm
0135-10002	LCD8-14A-L	#8 AWG	180	20
0135-10003	LCD6-14A-L	#6 AWG or #6 Weld	180	20
0135-10004	LCD4-14A-L	#4 AWG or #4 Weld	180	20
0135-10005	LCD2-56B-Q	#2 AWG	180	20
0135-10006	LCD1-56C-E	#1 AWG or #2 Weld	180	20
0135-10007	LCD1/0-12-X	#1/0 AWG or #1 Weld	480	54
0135-10008	LCD2/0-12-X	#2/0 AWG or #1/0 Weld	480	54
0135-10009	LCD3/0-12-X	#3/0 AWG or #2/0 Weld	480	54
0135-10010	LCD4/0-12-X	#4/0 AWG or #3/0 Weld	480	54
0135-10011	LCD250-12-X	250 MCM or #4/0 Weld	480	54
0135-10012	LCD300-12-X	300 MCM	480	54
0135-10013	LCD350-12-6	350 MCM	480	54
0135-10014	LCD400-12-6	400 MCM	480	54
0135-10015	LCD500-12-6	500 MCM	480	54

Note: NEMA standard two hole copper crimp lugs only.

Ordering Information for MaxPac III

Model SCR Power Pack

MXPC III Three Phase Six SCR Power Pack

Code Control Configuration

5 Proportional Control, DOT Zero-Crossover Firing, Command Input Signals: 4-20 mA, 0-5 VDC, 1-5 VDC (via Modbus RTU/485 only), 0-10 VDC, Remote 0-1000 OHM Potentiometer w/Manual Override, Modbus RTU/RS485 Communications. RTD Heat Sink Temperature Sensor with Two Set-Points, Automatic Line Sensing 50/60HZ, Remote Permissive Stop Input, Form "C" Dry Contact Alarm Output, Staged Heating w/Digital Calibration Zero / Span Adjustments(4-8 mA, 8-12 mA, 12-16 mA, 16-20 mA(via Modbus RTU/RS485 only), LED Diagnostics: Command Input, Main/Trigger Boards Running, SCR Status per Phase, Diagnostic Kit via Modbus RTU/RS485: Highest Heat Sink Temperature, Last Heat Sink Temperature, Highest and Lowest Ambient Temperature, Line Frequency Monitoring, Third Party Certifications: UL, cUL, CE, DEMKO (650A and below).

Code Current at 50°C (122°F)

01	100 Amp	Open Design
02	100 Amp	Touch Safe Design
03	150 Amp	Open Design
04	150 Amp	Touch Safe Design
05	200 Amp	Open Design
06	200 Amp	Touch Safe Design
07	300 Amp	Open Design
08	300 Amp	Touch Safe Design
09	400 Amp	Open Design
10	400 Amp	Touch Safe Design
11	550 Amp	Open Design
12	550 Amp	Touch Safe Design
13	650 Amp	Open Design
14	650 Amp	Touch Safe Design
15	800 Amp	Open Design
16	1000 Amp	Open Design
17	1200 Amp	Open Design

Code Line Voltage

1	120 VAC - 480VAC
2	575/600 VAC

Code Instrument Power

1	120 VAC 50/60 Hz
2	230 VAC 50/60 Hz

Code Compression Lug Kits (Open Design up to 300 Amps)

For Other Ranges See Crimp Lug Chart

L0	None
L1	100 - 150 Amp PAK 1(#2 - 4/0)/connection
L2	200 - 300 Amp PAK 1(1/0 - 500mcm)/connection

Note: 550-1200 Amp and all Touch-Safe Designs: Buss

MXPC III - 5 04 1 1 L1 (Continued on next page)

Ordering Information for MaxPac III (continued)

Code	Fusing Option (1)						
	For < 500VAC Applications, Select One						
F00	None						
F01	100 -150 Amp PAK (200 Amp Fuse)						
F02	200 Amp PAK (250 Amp Fuse)						
F03	300 Amp PAK (400 Amp Fuse)						
F04	400 Amp PAK (500 Amp Fuse)						
F05	550 Amp PAK (700 Amp Fuse)						
F06	650 Amp PAK (800 Amp Fuse)						
F07	800 Amp PAK (1000 Amp Fuse)						
F08	1000 Amp PAK (1200 Amp Fuses)						
F09	1200 Amp PAK (Two 1000 Amp Fuses)						
	700 V Fuses for 575 V Applications, Select One						
F10	100 Amp PAK (125 Amp Fuse)						
F11	150 Amp PAK (175 Amp Fuse)						
F12	200 Amp PAK (250 Amp Fuse)						
F13	300 Amp PAK (400 Amp Fuse)						
F14	400 Amp PAK (500 Amp Fuse)						
F15	550 Amp PAK (700 Amp Fuse)						
F16	650 Amp PAK (800 Amp Fuse)						
F17	800 Amp PAK (1000 Amp Fuse)						
F18	1000 Amp PAK (1200 Amp Fuse)						
F19	1200 Amp PAK (Two 1000 Amp Fuses)						
Code	Remote Manual Adjust						
0	None						
1	Pot with 0 - 100% dial and Local/Remote Single Turn 1KΩ Potentiometer (Proportional Control Only) (Supplied loose for customer mounting)						
MXPC III - 5	04	1	1	L1	F02	1	Typical Model Number

- 1) SCR Fusing is for semiconductor protection only, not wire protection.
- 2) Supplied Loose for Customer Mounting.

Note:
Storage Temperature 14°F to 158°F
(-10°C to 70°C).

Crimp Lug Chart				
Chromalox #	Panduit #	Conductor Size	Torque	
			In-Lb.	Nm
0135-10002	LCD8-14A-L	#8 AWG	180	20
0135-10003	LCD6-14A-L	#6 AWG or #6 Weld	180	20
0135-10004	LCD4-14A-L	#4 AWG or #4 Weld	180	20
0135-10005	LCD2-56B-Q	#2 AWG	180	20
0135-10006	LCD1-56C-E	#1 AWG or #2 Weld	180	20
0135-10007	LCD1/0-12-X	#1/0 AWG or #1 Weld	480	54
0135-10008	LCD2/0-12-X	#2/0 AWG or #1/0 Weld	480	54
0135-10009	LCD3/0-12-X	#3/0 AWG or #2/0 Weld	480	54
0135-10010	LCD4/0-12-X	#4/0 AWG or #3/0 Weld	480	54
0135-10011	LCD250-12-X	250 MCM or #4/0 Weld	480	54
0135-10012	LCD300-12-X	300 MCM	480	54
0135-10013	LCD350-12-6	350 MCM	480	54
0135-10014	LCD400-12-6	400 MCM	480	54
0135-10015	LCD500-12-6	500 MCM	480	54

Note: NEMA standard two hole copper crimp lugs only.