Installation Instructions

DS-50D Disconnect Switch for Model HD3D Unit Heaters





Warnings

Failure to understand and follow these instructions and the **"WARNING"** notes therein may result in serious personal injury from electrical shock, or from the heater falling due to faulty installation.

AWARNING

ELECTRIC SHOCK HAZARD. Disconnect all power before installing or servicing heater. Failure to do so could result in personal injury or property damage. Heater must be installed by a qualified person in accordance with the National Electrical Code, NFPA 70.

AWARNING

ELECTRIC SHOCK HAZARD. Any installation involving electric heaters must be performed by a qualified person and must be effectively grounded in accordance with the National Electrical Code to eliminate shock hazard.

Package Contents

Item	Quantity	Part Number	Description	
A	1	304873006	Disconnect Switch Cover Assembly	
В	1	304873006	Disconnect Housing Assembly	
С	1	058038016	Slotted Mounting Bracket	
D	1	058038015	Base Mounting Bracket	

Item	Quantity	Part Number	Description	
E	2	048849058	1 1/2" long 8-32 Machine Screw	
F	8	048849023	5/8" long 10-32 Machine Screw	
G	4	049592055	8-32 K-nuts	
Н	2	049592058	10-32 K-nuts	9 9
I	1	305629016	Ground wire, 10 Gauge, green	
J	3	029205016	Power wires, 8 Gauge, black	
K	4	075456007	1 1/4 conduit nipple	
L	4	075572002	10-32 lock washers	000
М	1	010712053	Gasket	

Disconnect Switch Installation

Note: Fasteners should be tightened according to standard torque specs for stainless steel fasteners.


1. Loosen two (2) capture screws and open hinged front cover of control panel.




 Remove Disconnect Switch Cover Assembly (Item A) from Disconnect Housing Assembly (Item B) by loosening four (4) capture screws.




3. Insert conduit nipple (Item K) into knockout from inside of control panel.



4. Place Neoprene gasket (Item M) over conduit nipple on outside of control panel housing.




5. Screw conduit nipple (Item K) into conduit on Disconnect Housing Assembly (Item B) so that the Disconnect Housing Assembly extends toward the back of the heater. Do not fully tighten.



 Place lock washers on 1-1/2 x 8-32 machine screws (Item E) and insert into Disconnect Housing Assembly.



7. Place Base Mounting Bracket (Item D) on two machine screws between remaining lock-washers and 8-32 k-nuts (Item G) and fully tighten.



 Secure Slotted Mounting Bracket (Item C) to heater frame using (2) 5/8 x 10-32 machine screws (Item F). Fully tighten.



9. Attach Slotted Mounting Bracket (Item C) to Base Mounting Bracket by inserting (2) 5/8 x 10-32 machine screws (Item F) through slots and into threaded holes. Secure using remaining 8-32 k-nuts (Item G). Fully tighten.





Note: There are 4 threaded holes on the Base Mounting Bracket to allow for assembly to be installed on different heater housing sizes. 2-20kW heaters should use threaded holes farthest from the L-bend in the bracket and 25-39kW heater should use holes closest to the L-bend.

10. Fully tighten conduit nipple using 1-3/4" wrench


Disconnect Switch Wiring

11. Feed black and green jumper wires through disconnect enclosure and into control enclosure.






12. Connect black jumper wires to contactor terminals and green jumper wire to ground lug.



13. Install black jumper wires into disconnect terminals.



14. With disconnect installed, incoming power should be routed through disconnect enclosure conduit opening. Power wires should be installed in the remaining disconnect terminals and the ground wire should be spliced to the ground jumper wire using a wire nut.



Elements

Part Number	Description	Item
010712053	Gasket	M
304873006	TERMINAL BOX-DIS. SWITCH	A & B
048849023	5/8 x 10-32 Machine Screws	F
075572002	10-32 Lock Washers	L
075456007	1 1/4 Conduit Nipple	K
049592055	8-32 K-Nuts	G
048849058	1 1/2 x 8-32 Machine Screws	Е
058038016	Slotted Mounting Bracket	С
058038015	Base Mounting Bracket	D
029205016	8 Gauge Black Power Jumper Wires	J
305629016	10 Gauge Green Ground Jumper Wire	I
049592058	10-32 K-Nuts	Н

Limited Warranty:Please refer to the Chromalox limited warranty applicable to this product at http://www.chromalox.com/customer-service/policies/termsofsale.aspx.

Chromalox, Inc. 1347 Heil Quaker Boulevard Lavergne, TN 37086 (615) 793-3900 www.chromalox.com