



© 2026 Chromalox, Inc.

QUICK INSTALLATION GUIDE

- Step 1
- Warnings and safety
 - Package Contents
 - Display and keys
 - Mounting
 - Fasteners
 - Fast configuration

- Step 2
- Setting up quick configuration
 - Drilling dimensions and templates
 - Technical specifications

WARNINGS AND SAFETY

ES Although all of the information in this manual has been carefully checked, Chromalox assumes no liability, explicit or implied, for the presence of any errors or regarding damage to property and/or harm to individuals due to any improper use of this manual.

Chromalox also reserves the right to make changes to the contents and form of this manual and to the characteristics of the device illustrated at any time and without prior warning.

The revision of the notices illustrated in the manual must be carried out by qualified technicians in compliance with the requirements of the applicable standards. The use of the notices is essential. It is advisable to always check the possibility of checking the manuals. As use in conjunction with alarms is essential, it is advisable to always check the possibility of checking the intervention of the alarms during regular operation.

Before installing with the following temperature controllers: 116 (DN 6150), the operator must receive full training in the procedures for installation, maintenance and use that can be found in the installation manual for the device and its accessories. More information on the device and procedures of the installation, maintenance and use can be found in the installation manual and User Controllers (6150-4150), which is available for free download from the Chromalox website (www.chromalox.com).

CE EMC (electromagnetic compatibility) conforms to directive 2014/53/EU with reference to standard EN 61326-1
 EN 61326-2
 emission in industrial environment class A for models 6140 LV
 emission in residential environment class B for models 6140 HV
 Safety LVD conforms to directive 2014/35/EU with reference to standard EN61010-1

This is a class A product intended for use in an industrial environment. There may be potential difficulties in ensuring electromagnetic.

Graphic symbol

- ES** Indicates contents of sections, general instructions, notes, and other points to which the reader's attention needs to be called.
- CAUTION** Indicates a particularly delicate situation that could affect the safety or correct operation of the controller, or an instruction that MUST be followed to prevent hazards.


DISPOSAL

Controllers must be disposed of in conformity with current laws and regulations. If not correctly disposed of, some of the components used in the devices may harm the environment.

PACKAGE CONTENTS

- n. 1 PD Temperature Controller 116 (DN model 6150)
- n. 1 Mounting bracket with screws
- n. 1 Flasher bracket 16x36 16x36
- n. 1 Instruction sheet

DISPLAY AND KEYS



- Temperature unit of measurement.
- AUXILIARY STATUS.
- Light from keys (glows) over the value of the parameter displayed on the SV or PV display.
- F key: lets you navigate among controller menus and parameters. Confirms the parameter value and selects the next parameter.
- SV display: Alarm 1 limit, description of parameter, diagnostics and alarm messages. It can be used to view the alarm limit and in display process variable, parameter values. If the message SV - Err means that the sensor is not connected or is shorted.
- Light from keys (glows) over the value of the parameter displayed on the SV or PV display.
- F key: lets you navigate among controller menus and parameters. Confirms the parameter value and selects the next parameter.
- SV display: Alarm 1 limit, description of parameter, diagnostics and alarm messages. It can be used to view the alarm limit and in display process variable, parameter values. If the message SV - Err means that the sensor is not connected or is shorted.

MOUNTING

Attention! The devices described in this manual must be installed by trained personnel in conformity to current laws and regulations, following all of the instructions in this manual.

Before installing, check that the controller is in perfect condition and was not damaged in shipment. Make sure that the package contains all of the accessories listed on the accompanying document, especially the gasket and screws. Check that the order code matches the configuration required for the intended application (supply voltage, number and type of inputs and outputs).

Attention! If even one of the requirements mentioned above (trained technician in, device in perfect condition, correct configuration) is not satisfied, interrupt the installation and contact Chromalox Customer Service.

The controller is designed for permanent indoor installation. It must be mounted on electrical panels or on panels controlling machines or production process plants that are safe to protect the exposed terminals on the rear of the controller.

Attention! DO NOT install the controller in a potentially inflammable or explosive atmosphere. It can be connected to elements that work in such atmospheres only by means of appropriate interfaces that conform to safety regulations.

Attention! If the controller is used in applications with risk of electromagnetic interference, it MUST be connected to dedicated alarm devices. It is advisable to provide the possibility of checking whether any alarms have tripped.

The controller must be installed in a location that is not subject to sudden temperature changes or to freezing or condensation, and no corrosive gases must be present.

The controller can work in Pollution Degree 2 environments (presence of non-conductive dust, only temporarily conductive dust) but not allow soap or metal particles from machining or condensation products to reach the device.

The controller is sensitive to strong electromagnetic fields. Do not position it near radio devices or other equipment that may generate electromagnetic fields, such as power converters, relays, thyristor power units (especially phase angle), motors, solenoids, transformers, high-frequency welders, etc.

For correct installation, respect the dimensions of each hole and the distance between adjacent holes shown in the figures.

Attention! The support on which the operator panel is mounted must:

- be sufficiently rigid and robust to support the device without bending during use;
- be from 1 to 4 mm thick to allow the device to be fastened with the supplied bracket.

The front of the controller has an IP65 protection index, so the device can be installed without problems in rooms that are very dusty or subject to splashing water provided the housing in which the device is inserted is dust-tight and watertight. The controller is not suitable for use in outdoor environments. The device is fully protected by the support that is provided. If not adequately protected, the controller has an IP20 protection index (rear container and terminal board).


The controller can support a distance from 10 to 55 Hz, 20 m/s² in all directions (X, Y and Z). If the device is mounted on a support that exceeds these limits, it is advisable to provide a suspension system to reduce vibrations.

The temperature in the housing containing the controller must NEVER exceed 55°C. NEVER block the ventilation slots. Forced cooling (for example, with a fan of the rear of the controller) may cause measurement errors.


The controller must be positioned so that the display is not subject to direct sunlight or to very strong sources of light. If necessary, filter direct light, for example, with a thin sheet of the rear of the controller may cause measurement errors.

The controller must be fixed between 30° and 120°.

- Remove the screws that are placed between the controller and the panel. The gasket (supplied) is indispensable for ensuring the airtightness of the panel.
- Insert the device into the hole previously made on the panel.
- Mark the supplied brackets onto the rear of the controller.
- Tighten the screws to fasten the device in the panel. The tightening torque must be between 0.3 and 0.4 N.m.



CONNECTIONS



Connected external circuits must have double isolation. In case of shielded cables, the shield must be grounded at a single point, possibly near the controller. Input cables must be physically separated from power cables, output cables, and power connections. To avoid electrical interference, loose terminals may cause sparks and fires. The recommended lightning impulse is 0.5 kV. When making connections, respect polarity where required.

Do not bend or twist the cables beyond the limits specified by the manufacturers. The terminal block limit and define the correct direction for applying the cover. Always use cables appropriate for the voltage and current limits specified in the Technical Characteristics.

Use copper cables with 60/75°C insulation. Use shielded and twisted cables for non-power connections. The controller's terminal board has screw terminals (M3) that accept stripped cables and correct terminals for a lightning surge of 0.5 N.m. Two ring or crimped fork terminals can be connected on each terminal.

Cable / terminal	Cable section / terminal	Terminal size
Shield cable	0.2 - 2.5 mm ² (24 - 14 AWG)	0.8 mm
Twisted	0.2 - 2.5 mm ² (24 - 14 AWG)	0.8 mm
Power cables (to be connected)	0.25 - 2.5 mm ² (24 - 14 AWG)	0.8 mm
Ring terminal (to be connected)	0.25 - 2.5 mm ² (24 - 14 AWG)	0.8 mm

Attention! Before powering the controller, make sure that the supply voltage matches the one shown on the controller data plate.

Because the controller does not have a switch, a higher switch with less must be inserted before the switch. The switch or relay must be positioned in the immediate vicinity of the device and must be easily reached by the operator. A single switch can control multiple controllers.

The controller must be powered by a line separated from the one used for electromechanical power devices (relays, contactors, solenoids, etc.). It is advisable to install a ferrite core on the power line, as close as possible to the device, to limit the controller's susceptibility to electromagnetic noise.

If the controller's power line is heavily disturbed by the switching of thyristor power units or by motors, it is advisable to use an isolation transformer only for the controller, grounding the sheet. Use appropriate line filters in the vicinity of high-frequency generators or arc welders. Use a voltage stabilizer if there are wide swings in the voltage.

20-27 VAC/0-100V must be powered by a class II or low-voltage limited-energy source. The power supply must use a partition separated from the system or machine power cables, and low-voltage power cables must run along a path separated from the system or machine power cables.

Attention! Make sure the ground connection is efficient.

- absent or inefficient grounding can make the device unstable due to excessive noise. Specifically, check that:
- resistance is < 6 Ω.

Attention! If the controller is connected to devices that are NOT electrically isolated (such as thermocouples), the controller's input and output lines must be separated from the power line.

To prevent noise, the controller's input and output cables must be kept away from the power cables (high voltages or high currents). Input and output cables and the power cables must not be placed parallel to one another. Use shielded cables or separate cable trays.


To connect the output to an inductive load (relay, contactor, electrovalve, motor, fan, solenoid, etc.) that works in AC, mount a snubber, i.e., an RC group (resistor and condenser in series) placed parallel to the load.

NOTE: All condensers must conform to VDE (BSS X2) standards and support voltage > 220 VAC. The power of the resistor must be > 2 W.

For inductive loads that work in DC, mount a 1MΩ/0.7 μF diode parallel to the coil.

The filters must be connected as close as possible to the controller.

FAST CONFIGURATION MENU



NOTE: The full configuration menu is protected by 2 passwords that allow access to two different menu sections.

- Password 1 = 1
- Password 2 = 2

For full details please review the long-form manual.



© 2026 Chromalox, Inc.

QUICK INSTALLATION GUIDE

- Site 1
Warnings and safety
Package Contents
Display and keys
Mounting
Wiring
Fast configuration

Site 2

- Setting up quick configuration
Drilling dimensions and templates
Technical specifications

WARNINGS AND SAFETY

⚠️ *Although all of the information in this manual has been carefully checked, Chromalox assumes no liability regarding the presence of any errors or regarding damage to property and/or harm to individuals due to any improper use of this manual.*


⚠️ *Chromalox also reserves the right to make changes to the contents and form of this manual and to the characteristics of the device illustrated in any time and without prior warning.*

⚠️ *The device must be installed and used in accordance with the instructions provided in this manual. The user must read and understand the contents of this manual and be aware of the safety instructions contained in the manual.*

⚠️ *If the IP20 temperature controller 14 DM 4150 is used in applications with the risk of damage to persons, machinery or materials, its use in conjunction with alarms is essential. It is advisable to envisage the possibility of choosing the appropriate type of alarm and to read the instructions for use.*

⚠️ *For the correct use of the device, the user must read the instructions for use and the instructions for the maintenance of operation, emergency, diagnosis and maintenance of the device.*

⚠️ *More information on the device and procedures of the installation, maintenance and use can be found in the installation and Use Controllers, which is available for free download from the Chromalox website (www.chromalox.com).*



EMC electromagnetic compatibility conforms to directive 2014/53/EU with reference to standard EN61010-1
EN61506-1
EN61506-2
EN61506-3
EN61506-4
EN61506-5
EN61506-6
EN61506-7
EN61506-8
EN61506-9
EN61506-10
EN61506-11
EN61506-12
EN61506-13
EN61506-14
EN61506-15
EN61506-16
EN61506-17
EN61506-18
EN61506-19
EN61506-20
EN61506-21
EN61506-22
EN61506-23
EN61506-24
EN61506-25
EN61506-26
EN61506-27
EN61506-28
EN61506-29
EN61506-30
EN61506-31
EN61506-32
EN61506-33
EN61506-34
EN61506-35
EN61506-36
EN61506-37
EN61506-38
EN61506-39
EN61506-40
EN61506-41
EN61506-42
EN61506-43
EN61506-44
EN61506-45
EN61506-46
EN61506-47
EN61506-48
EN61506-49
EN61506-50
EN61506-51
EN61506-52
EN61506-53
EN61506-54
EN61506-55
EN61506-56
EN61506-57
EN61506-58
EN61506-59
EN61506-60
EN61506-61
EN61506-62
EN61506-63
EN61506-64
EN61506-65
EN61506-66
EN61506-67
EN61506-68
EN61506-69
EN61506-70
EN61506-71
EN61506-72
EN61506-73
EN61506-74
EN61506-75
EN61506-76
EN61506-77
EN61506-78
EN61506-79
EN61506-80
EN61506-81
EN61506-82
EN61506-83
EN61506-84
EN61506-85
EN61506-86
EN61506-87
EN61506-88
EN61506-89
EN61506-90
EN61506-91
EN61506-92
EN61506-93
EN61506-94
EN61506-95
EN61506-96
EN61506-97
EN61506-98
EN61506-99
EN61506-100


⚠️ This is a class A product intended for use in an industrial environment. There may be potential difficulties in ensuring electromagnetic.

Graphic symbol
⚠️ Indicates contents of sections, general instructions, notes, and other points to which the reader's attention needs to be called.
⚠️ Indicates a particularly delicate situation that could affect the safety or correct operation of the controller, or an instruction that MUST be followed to prevent hazards.

DISPOSAL
⚠️ The controllers must be disposed of in conformity to current laws and regulations.
⚠️ If not correctly disposed of, some of the components used in the devices may harm the environment.

PACKAGE CONTENTS
n. 1 PFD Temperature Controller / 14 DM model
n. 2 Mounting bracket with screws
n. 1 Rubber gasket 48-56 mm-10x
n. 1 Installation Sheet

DISPLAY AND KEYS



- Temperature unit of measurement or number of program runs.
- Setpoint of outputs OUT1, OUT2, OUT3, OUT4.
- Display program number, step number, unit of measurement (% A, kW, kWh).
- Controller function status: RUN = setpoint programmer active; _ = setpoint ramp active; TON = PFD parameters tuning active; _ = manual control; FEN = remote setpoint enabled; SP 1/2 = setpoint active (01 = setpoint 1, 02 = setpoint 2).
- Work mode key (manual/automatic) in standard mode.
- Function key (assign two parameter bits). The key is active when the display shows the parameter bit and but.
- Key function combination with alphanumeric keypad and but.
- Up/down keys: raise/lower the value of the parameter display- variable.
- Key pressed signal.
- Display percentage of power or current, configurable with parameter bit4.
- Display F- parameters, diagnostics and alarm messages. Configurable with parameter bit5 (default = setpoint).
- Display F- parameter values. Configurable with parameter bit5 (default = setpoint).

MOUNTING

⚠️ Attention! The devices described in this manual must be installed by trained personnel in conformity to current laws and regulations, following all of the instructions in this manual.

Before installing, check that the controller is in perfect condition and was not damaged in shipment. Make sure that the package contains all of the accessories listed on the accompanying document, especially the gasket and the fastening brackets.

Check that the order code matches the configuration required for the intended application (supply voltage, number and type of inputs and outputs).

⚠️ Attention! If even one of the requirements mentioned above (trained technician in device in perfect condition, correct configuration) is not satisfied, interrupt the installation and contact your dealer or dealer Distributor.

The controller is designed for permanent indoor installation. It must be mounted on electrical panels or on racks controlling machines or production process plants that are safe to protect the exposed terminals on the rear of the controller.

⚠️ Attention! DO NOT install the controller in a potentially inflammable or explosive atmosphere. It can be connected to elements that work in such atmospheres only by means of appropriate interfaces that conform to safety regulations in force in the country of installation.

⚠️ Attention! If the controller is used in applications with risk of harm/damage to persons/property, it MUST be connected to dedicated alarm devices. It is advisable to provide the possibility, during normal functioning of the controller and of the system or equipment that it controls, of checking whether any alarms have tripped.

The controller must be installed in a location that is not subject to sudden temperature changes or to freezing or condensation due to possible condensation.

Do not allow scrap or metal particles from machining or condensation products to reach the device.

The controller is suitable for strong electromagnetic fields. Do not position it near radio devices or other equipment that may generate electromagnetic fields, such as power converters, UPSs, thyristor power units (especially phase angle), motors, solenoids, transformers, high-frequency welders, etc.

For correct installation, respect the dimensions of each hole and the distance between adjacent holes shown in the figures.

⚠️ Attention! The support on which the operator panel is mounted must:

- be sufficiently rigid and robust to support the device without bending under its weight;
- be from 1 to 4 mm thick to allow the device to be fastened with the supplied brackets.

The front of the controller has an IP20 protection index, so the device can be installed without problems in rooms that are very dusty or subject to splashing water provided the housing in which the device is inserted is dust-tight and water-tight.

Surprisingly respects the specified drilling dimensions; the device is fully registered to the support to ensure that the gasket is not adequately protected, the controller has an IP20 protection index (rear container and terminal board).

The controller can support vibrations from 10 to 50 Hz, 20 ms⁻², in all directions (X, Y and Z). If the device is mounted on a support that exceeds these limits, it is advisable to provide a suspension system to reduce vibrations.

The temperature in the housing containing the controller must NEVER exceed 55°C. NEVER block the ventilation slots. Forced cooling (for example, with a fan) of the rear of the controller may cause measurement errors.

The controller must be protected so that the display is not subject to direct sunlight or to very strong sources of light. The operator panel must be protected with a clear support.

The controller must be fitted with a rubber gasket, with a section of 30 mm x 10 mm x 10 mm.


The controller must be fitted with a rubber gasket, with a section of 30 mm x 10 mm x 10 mm.

The controller must be fitted with a rubber gasket, with a section of 30 mm x 10 mm x 10 mm.


The controller must be fitted with a rubber gasket, with a section of 30 mm x 10 mm x 10 mm.

The controller must be fitted with a rubber gasket, with a section of 30 mm x 10 mm x 10 mm.

The controller must be fitted with a rubber gasket, with a section of 30 mm x 10 mm x 10 mm.



CONNECTIONS



Connected external circuits must have double isolation. In case of shielded cables, the shield must be grounded at a single point, possibly near the controller. Input cables must be physically separated from power cables, output cables, and power connections. Do not connect thermocouples to the terminals. Loose terminals may cause sparks and fires. The recommended lightning torque is 0.5 Nm. When making connections, respect polarity where required.

Do not bend or twist the cables beyond the limits specified by the manufacturers.

After connecting the cables, apply the transparent cover to protect the terminal. The terminal health limit and define the correct connection sequence.

Always use cables appropriate for the voltage and current limits specified in the Technical Characteristics.

Use copper cables with 60/75°C insulation.

Use twisted and shielded cables for non-power connections.

The controller's terminal board has screw terminals (M3) that accept stripped cables and crimped terminals for a lightning torque of 0.5 N m.

Two ring or crimped fork terminals can be connected on each terminal.

Cable / Terminal	Cable section / Terminal	Terminal size
Shielded cable	0.2 - 2.5 mm ² (24 - 14 AWG)	0.8 mm
Twisted	0.2 - 2.5 mm ² (24 - 14 AWG)	0.8 mm
Flat terminal (to be crimped)	0.25 - 2.5 mm ² (24 - 14 AWG)	5.8 mm
Ring terminal (to be crimped)	0.25 - 2.5 mm ² (24 - 14 AWG)	5.8 mm

Attention! Anchor the cables, at least in pairs, so that mechanical stresses do not discharge on the terminal connections.

Attention! Before powering the controller, make sure that the supply voltage matches the one shown on the controller data plate.

Because the controller does not have a switch, a bipolar switch with fuse must be inserted in the line. The switch or selector must be positioned in the immediate vicinity of the device and must be easily reached by the operator. A single switch can control multiple controllers.

The controller must be powered by a line separated from the one used for electromechanical power devices (relays, contactors, solenoids, etc.).

It is advisable to install a ferrite core on the power line, as close as possible to the device, to limit the controller's susceptibility to electromagnetic noise.

If the controller's power line is heavily disturbed by the switching of thyristor power units or by motors, it is advisable to use an isolation transformer only for the controller, grounding the shield.

Use a 20-27 VAC/DC module must be powered by a class II or low-voltage (high-energy) source. The power supply must use a line separated from the one used for electromechanical power devices, and low-voltage power cables must not share a path with the system or machine power cables.

⚠️ Attention! Make sure the ground connection is efficient. Absent or inefficient grounding can make the device susceptible due to excessive noise.

⚠️ Attention! Specifically, check that:

- the ground is connected to the earth;
- the resistance is < 0.2 Ω.

⚠️ Attention! If the controller is connected to devices that are NOT electrically isolated (such as thermocouples), ground with a specific conductor to prevent grounding directly through the machine structure.

The controller's input and output lines must be separated from the power lines. To prevent noise, the controller's input and output cables must be kept away from the power cables (high voltages or high currents).

The input and output cables and the power cables must not be placed parallel to one another. Use shielded cables or separable cable trays.


To connect the output to an inductive load (relay, contactor, electrovalve, motor, fan, solenoid, etc.) that works in A.C., mount a suitable L-C-R-RC group (resistor and condenser in series) placed parallel to the load.

Installing this filter requires the life of the relay.

NOTE: All condensers must conform to VDE (class X2) standards and support voltage ≥ 230 VAC. The power of the resistor must be ≥ 1 W.

For inductive loads that work in DC, mount a 1N4007 diode parallel to the coil.

FAST CONFIGURATION MENU



NOTE: The full configuration menu is protected by 2 passwords that allow access to two different menu sections.

- Password 1 = 1
- Password 2 = 2

For full details please review the full-format manual.

COMMISSIONING WITH QUICK CONFIGURATION

1 INPUT CONNECTION

Linear input voltage

3 1 V (R = 15 kΩ)

4 5 V (R = 15 kΩ)

5 12 V (R = 15 kΩ)

6 24 V (R = 15 kΩ)

7 0 V (R = 15 kΩ)

8 0 V (R = 15 kΩ)

9 0 V (R = 15 kΩ)

10 0 V (R = 15 kΩ)

11 0 V (R = 15 kΩ)

12 0 V (R = 15 kΩ)

13 0 V (R = 15 kΩ)

14 0 V (R = 15 kΩ)

15 0 V (R = 15 kΩ)

16 0 V (R = 15 kΩ)

17 0 V (R = 15 kΩ)

18 0 V (R = 15 kΩ)

19 0 V (R = 15 kΩ)

20 0 V (R = 15 kΩ)

21 0 V (R = 15 kΩ)

22 0 V (R = 15 kΩ)

23 0 V (R = 15 kΩ)

24 0 V (R = 15 kΩ)

25 0 V (R = 15 kΩ)

26 0 V (R = 15 kΩ)

27 0 V (R = 15 kΩ)

28 0 V (R = 15 kΩ)

29 0 V (R = 15 kΩ)

30 0 V (R = 15 kΩ)

31 0 V (R = 15 kΩ)

32 0 V (R = 15 kΩ)

33 0 V (R = 15 kΩ)

34 0 V (R = 15 kΩ)

35 0 V (R = 15 kΩ)

36 0 V (R = 15 kΩ)

37 0 V (R = 15 kΩ)

38 0 V (R = 15 kΩ)

39 0 V (R = 15 kΩ)

40 0 V (R = 15 kΩ)

41 0 V (R = 15 kΩ)

42 0 V (R = 15 kΩ)

43 0 V (R = 15 kΩ)

44 0 V (R = 15 kΩ)

45 0 V (R = 15 kΩ)

46 0 V (R = 15 kΩ)

47 0 V (R = 15 kΩ)

48 0 V (R = 15 kΩ)

49 0 V (R = 15 kΩ)

50 0 V (R = 15 kΩ)

51 0 V (R = 15 kΩ)

52 0 V (R = 15 kΩ)

53 0 V (R = 15 kΩ)

54 0 V (R = 15 kΩ)

55 0 V (R = 15 kΩ)

56 0 V (R = 15 kΩ)

57 0 V (R = 15 kΩ)

58 0 V (R = 15 kΩ)

59 0 V (R = 15 kΩ)

60 0 V (R = 15 kΩ)

61 0 V (R = 15 kΩ)

62 0 V (R = 15 kΩ)

63 0 V (R = 15 kΩ)

64 0 V (R = 15 kΩ)

65 0 V (R = 15 kΩ)

66 0 V (R = 15 kΩ)

67 0 V (R = 15 kΩ)

68 0 V (R = 15 kΩ)

69 0 V (R = 15 kΩ)

70 0 V (R = 15 kΩ)

71 0 V (R = 15 kΩ)

72 0 V (R = 15 kΩ)

73 0 V (R = 15 kΩ)

74 0 V (R = 15 kΩ)

75 0 V (R = 15 kΩ)

76 0 V (R = 15 kΩ)

77 0 V (R = 15 kΩ)

78 0 V (R = 15 kΩ)

79 0 V (R = 15 kΩ)

80 0 V (R = 15 kΩ)

81 0 V (R = 15 kΩ)

82 0 V (R = 15 kΩ)

83 0 V (R = 15 kΩ)

Probe type is set with the parameter

WFE

LED Out2: OFF

LED Out3: OFF

LED Out4: ON

LED Out5: ON

LED Out6: ON

LED Out7: ON

LED Out8: ON

LED Out9: ON

LED Out10: ON

LED Out11: ON

LED Out12: ON

LED Out13: ON

LED Out14: ON

LED Out15: ON

LED Out16: ON

LED Out17: ON

LED Out18: ON

LED Out19: ON

LED Out20: ON

LED Out21: ON

LED Out22: ON

LED Out23: ON

LED Out24: ON

LED Out25: ON

LED Out26: ON

LED Out27: ON

LED Out28: ON

LED Out29: ON

LED Out30: ON

LED Out31: ON

LED Out32: ON

LED Out33: ON

LED Out34: ON

LED Out35: ON

LED Out36: ON

LED Out37: ON

LED Out38: ON

LED Out39: ON

LED Out40: ON

LED Out41: ON

LED Out42: ON

LED Out43: ON

LED Out44: ON

LED Out45: ON

LED Out46: ON

LED Out47: ON

LED Out48: ON

LED Out49: ON

LED Out50: ON

LED Out51: ON

LED Out52: ON

LED Out53: ON

LED Out54: ON

LED Out55: ON

LED Out56: ON

LED Out57: ON

LED Out58: ON

LED Out59: ON

LED Out60: ON

LED Out61: ON

LED Out62: ON

LED Out63: ON

LED Out64: ON

LED Out65: ON

LED Out66: ON

LED Out67: ON

LED Out68: ON

LED Out69: ON

LED Out70: ON

LED Out71: ON

LED Out72: ON

LED Out73: ON

LED Out74: ON

LED Out75: ON

LED Out76: ON

LED Out77: ON

LED Out78: ON

LED Out79: ON

LED Out80: ON

Linear input in direct

1 V (R = 15 kΩ)

5 V (R = 15 kΩ)

12 V (R = 15 kΩ)

24 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

Linear input in direct

1 V (R = 15 kΩ)

5 V (R = 15 kΩ)

12 V (R = 15 kΩ)

24 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)

0 V (R = 15 kΩ)