
Installation Instructions

DTS High Temperature

For use in Electrical Termination of Mineral Insulated Cables







DTS High Temperature Adaptor Kit

Kit Contents

Item	Qty	Description
2	1	Bracket
6	1	MI RTD

Tools Required for Kit Installation





General

The Chromalox DTS High Temp Adaptor Kit is used in conjunction with the DTS-HAZ to provide termination and control for MI series heating cables.

AWARNING

HAZARD OF ELECTRIC SHOCK. Disconnect all power before opening. All installations must be effectively grounded in accordance with the National Electrical Code to eliminate shock hazard. To avoid electrostatic discharge wipe with a damp cloth.

AWARNING

Turn off power before removing junction box cover at all times.

AWARNING

Users should install adequate controls and safety devices with their electric heating equipment. Where the consequences of failure may be severe, back-up controls are essential. Although the safety of the installation is responsibility of the user, Chromalox will be glad to assist in making equipment recommendations.

DTS High Temperature Adaptor Kit


For use with MI Mineral Insulated Heating Cables


Order Separately






Actual Kit Dimensions









- **1.** Strap bracket to pipe with pipe strap (Chromalox type PS not included).
- 2. Assemble junction box to fitting as shown (fitting must be properly rated for the area classification). Tighten locknut until the junction box bottoms out against the lip of the fitting. Attach RTD MI cable to fitting for watertight connection.



3. Use a CCH-2 (or equivalent) to connect tee condulet. Attach MI cable and conduit with drain.



4. Make electrical connections to MI cable and RTD as shown. For more details on wiring connections see the DTS-HAZ installation manual (PJ944).



Once connections are made, place cover on box and secure the lid to the box by tightly fastening screws.

Limited Warranty:Please refer to the Chromalox limited warranty applicable to this product at http://www.chromalox.com/customer-service/policies/termsofsale.aspx.

Chromalox, Inc. 1347 Heil Quaker Boulevard Lavergne, TN 37086 (615) 793-3900 www.chromalox.com